

# Readerware Symbol CS-2000 Barcode Reader Configuration

Version 1

To configure your Symbol CS-2000 Barcode Reader for use with Readerware products, simply scan down the page. Scan each barcode in order.

**Reset to default:**



**UPC/EAN Supplements:**



**Supplements auto discriminate:**

